



## TAKING GOOD CARE OF YOUR PRIMEWARE QUALITY MELAMINE PRODUCT

Thank you for choosing Primeware's Quality Melamine which with minimal care and maintenance you can keep its shine and prime appearance.

Whether you are using Primeware for day to day use or for special events, Quality Melamine will add style to your table or counter.

### How should I care for my product?

Before use: Remove any labels. Wash the dish in hot soapy water, rinse and dry thoroughly.

Quality Melamine is ideal for use in a chilled or ambient food display.

We recommend that products are not subjected to dramatic changes in temperature (e.g. directly from the refrigerator to the dishwasher or into hot water. The maximum temperature for Quality Melamine is 90°c. We do not recommend any of our items for use in an oven or microwave, heated counter or under any direct heat source as will cause them to permanently discolour and crack.

The Quality Melamine products are dishwasher safe. Do not use scouring pads or similar abrasive cleaning products as will scratch and cause the surface to become dull. Where stubborn food staining persists, soak in warm water and then wash.

Melamine is a tough product but should be treated like any fine tableware. To avoid chipping and breaking care should be taken with the products to avoid them hitting a hard surface.

